

2 Verity Memory

Power up and connect to the command line interface of the Digi device (i.e. telnet 192.168.1.1)



Enter the following command to see the Memory Module and available size. # > flashdrv



You should see results similar to the following:

Volume	Byte	Used	Available	Bad	Use%	Mounted on	
NO NAME	1043021824	16384	1043005440	0	0.0	A:/	

Note: Actual Bytes may vary from what is shown.

© Digi International, Inc., 2008

Digi, Digi International and the Digi logo are trademarks or registered trademarks of Digi International, Inc., in the United States and other countries worldwide. All other trademarks are property of their respective owners.

3 Read / Write Memory

Writing data to the module and reading data from the module is done through customized Python scripts. An example script can be obtained at http://www.digi.com/support. Select your product, and then select Sample Applications