

# RJ45 to DB9 Female Crossover Cable

This cable will allow you to connect from the CM32 serial ports to console ports, terminals, printers and any other DTE RS232 device.

The wiring diagram is shown in Table 1.

**Table 1: EIA-232 RJ45 to DB-9**

From Port RJ45	Signal	Signal	To Port DB-9F
3	TxD	RxD	2
6	RxD	TxD	3
4	GND	GND	5
2	DTR	DSR	6
		DCD	1
8	DSR	DTR	4
7	DCD		
1	RTS	CTS	8
5	CTS	RTS	7

