

1 Identify Contents



The information listed below is meant to help aid you in identifying the accessories included in your box. You may need to reference the product part number (X4-xxx-xxx-x) which is located on the Digi label on the outside of the box.




Quick Start Guide


ConnectPort™ X4 WiFi

90001233_A


a Identify XBee antenna




b Identify WiFi antenna



c Identify Ethernet Cable



d Identify Power Supply




e Identify Power Cord



[X4-xxx-xxx-A models only]

2 Connect Hardware

a Connect accessories as shown (1, 2, 3, 4, 5).



NOTE: The Power Supply has a twist-lock connector which can be secured by rotating it 90 degrees once installed into the ConnectPort X4.



What's Next?

Once you have verified the contents of your box and connected all hardware, please refer to the ConnectPort X4 Getting Started Guide which can be found at www.digi.com/connectportx4.