



Haxiot HXG3000 Indoor Gateway Quick Setup Guide

1



Unpack Haxiot HXG3000 Indoor Gateway

Package includes

- 1 x Haxiot HXG3000 Indoor Gateway
- 1 x Power supply
- 1 x Antenna with SMA connector
- 1 x Quick start guide

2



Setup & Connect the HXG3000 Gateway

Connect the supplied LoRa antenna to the HXG3000 gateway antenna port.

Connect the gateway to Internet using Ethernet (optional LTE will auto connect without Ethernet)

Connect the gateway to the provided DC power supply. Plug the power supply into a power outlet.

IMPORTANT: Only use the provided power supply and keep the antenna connected at all times.

3



Enable Haxiot Cloud Service



1. Setup your Haxiot X-ON cloud account at <https://signup.haxiot.com> and enter your activation code

4



Provisioning



Load scan.haxiot.com on your smartphone using the assigned Haxiot X-ON username and password.

Select the SCAN button to provision and test Gateway using the QR code on the gateway enclosure or packaging box.

Login to X-ON cloud at <https://us1.haxiot.com>

For a detailed user guide, visit [this link](#).

Caution: The Haxiot HXG3000 Indoor Gateway is a radio transmitting device. This device is for indoor use only.

Regulatory Notices:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.