How to update the firmware in the Digi Wi-Point 3G

On occasion it maybe necessary to update the firmware on the Digi Wi-Point 3G to include new features and bug fixes. The following instructions and screen shots will show how this is done.

First in the Wi-Point 3G WebUI select **Update Firmware** under **Administration**.



© 2008 Digi International Inc.

How to update the firmware in the Digi Wi-Point 3G

Then browse and select the firmware file that you down loaded from Digi's Support site.

Click on the **Upload firmware**.



© 2008 Digi International Inc.

How to update the firmware in the Digi Wi-Point 3G

You will then be presented with a Verify Upgrade firmware splash screen.

Click on **OK**.

The firmware will then upload to the Digi Wi-Point 3G and when it's finished it will reboot the unit.



© 2008 Digi International Inc.

How to update the firmware in the Digi Wi-Point 3G

When the unit reboots and comes back online after about 60 seconds you can verify the upgrade by
going to **System Information** in the **Administration** menu in the WebUI.



Your unit has been updated.

© 2008 Digi International Inc.